

Die Funkhandsender von Somfy im Überblick

Pure

Silver

Patio

Lounge

Telis 6
Chronis RTS



Telis 6 Chronis RTS
Pure
Art.Nr. 1 805 222



Telis 6 Chronis RTS
Silver
Art.Nr. 1 805 223

Telis 16 RTS



Telis 16 RTS
Pure
Art.Nr. 1 811 020



Telis 16 RTS
Silver
Art.Nr. 1 811 021

Telis Modulis
Soliris RTS



Telis Modulis
Soliris RTS Pure
Art.Nr. 1 810 764



Telis Modulis
Soliris RTS Silver
Art.Nr. 1 810 666



Telis Modulis
Soliris RTS Lounge
Art.Nr. 1 810 665

Telis 4
Modulis RTS



Telis 4 Modulis
RTS Pure
Art.Nr. 1 810 765



Telis 4 Modulis
RTS Silver
Art.Nr. 1 810 663



Telis 4 Modulis
RTS Lounge
Art.Nr. 1 810 664

Telis 1
Modulis RTS



Telis 1 Modulis
RTS Pure
Art.Nr. 1 810 974



Telis 1 Modulis
RTS Silver
Art.Nr. 1 810 975



Telis 1 Modulis
RTS Lounge
Art.Nr. 1 810 976

Telis 4
Soliris RTS



Telis 4 Soliris
RTS Pure
Art.Nr. 1 810 957



Telis 4 Soliris
RTS Silver
Art.Nr. 1 810 907



Telis 4 Soliris
RTS Patio
Art.Nr. 1 810 648



Telis 4 Soliris
RTS Lounge
Art.Nr. 1 810 906

Telis
Soliris RTS



Telis Soliris
RTS Pure
Art.Nr. 1 810 634



Telis Soliris
RTS Silver
Art.Nr. 1 810 909



Telis Soliris
RTS Patio
Art.Nr. 1 810 646



Telis Soliris
RTS Lounge
Art.Nr. 1 810 908

Telis 4
RTS



Telis 4
RTS Pure
Art.Nr. 1 810 631



Telis 4
RTS Silver
Art.Nr. 1 810 638



Telis 4
RTS Patio
Art.Nr. 1 810 644



Telis 4
RTS Lounge
Art.Nr. 1 810 651

Telis 1
RTS



Telis 1
RTS Pure
Art.Nr. 1 810 630



Telis 1
RTS Silver
Art.Nr. 1 810 637



Telis 1
RTS Patio
Art.Nr. 1 810 642



Telis 1
RTS Lounge
Art.Nr. 1 810 649